NC899IRR
MK4 Keyswitch Reset Point

Approved Document No: DNU3021414 Rev 1

ON
ISOLATED
Call

CE

−V +V SW

−V common negative
+V common positive
**SW** switched output.

The NC899IRR keyswitch reset point is designed to cancel emergency calls initiated by the NC312RXC master ceiling receiver.

It connects to the ceiling receiver as shown in the example configuration diagram (below right).

To operate, momentarily turn the keyswitch to ISOLATE before returning it to the ON position.

Important: Do not leave the keyswitch in the ISOLATE position as this will disable the receiver's emergency call facility (standard calls will still be received).

When in ISOLATE mode, the reset point's red LED will illuminate.

EXAMPLE CONFIGURATION

common positive

signal

TO PANEL

common negative

+V SR −V
+V SR −V IR
IR +V CR −V S RES SW
+V KR −V

CR = ceiling receiver (master).
SR = ceiling receiver (slave). KR = keyswitch reset point